




5 min.




x1

BLANCA




HOJA INSTRUCCIONES SERIE 2209_2210_2211_2212
INSTRUCTIONS LEAFLET SERIAL 2209_2210_2211_2212
BEDIENUNGSANLEITUNG 2209_2210_2211_2212

PIEZAS y HERRAMIENTAS
PARTS AND TOOLS
TEILE UND WERKZEUGE



A 8 M6x16	B 12 M6x16	C 8	
E 1 4mm	F 8 M6x21	K 4	L 2

06-05-2019





rocada

C/ de les Moreres s/n
08552 Taradell
Barcelona (Spain)

Phone +34 93 880 00 04
Fax +34 93 880 04 36

www.rocada.com
rocada@rocada.com




5 min.





x1

BLANCA




HOJA INSTRUCCIONES SERIE 2201_2202_2205_2206
INSTRUCTIONS LEAFLET SERIAL 2201_2202_2205_2206
BEDIENUNGSANLEITUNG 2201_2202_2205_2206

PIEZAS y HERRAMIENTAS
PARTS AND TOOLS
TEILE UND WERKZEUGE



06-05-2019



1

Kx4

2.

2

Cx1

x8

3.

3

Bx1

x4

Ax1

Dx1

4

1.

Fx8

Dx1

Fx8